

TAYAMA®



Model No.:TB-200

Instruction Manual

TAYAMA APPLIANCE USA INC
www.tayama-usa.com

CONTENT

2. Important safety instructions
4. Parts and features
5. How to operate
6. How to clean
6. Trouble shooting
7. Icy treats recipes
10. Adult Icy treats recipes

Adult Icy Treats Recipes

Frozen Pink Grapefruit Cosmopolitan

120ml pink grapefruit juice
60ml vodka
60ml of raspberry syrup
Ice

Place all ingredients except the ice in a bowl with paddle. Shave ice on SNOW CONE setting to desired consistency or until large serving ice line is reached and serve.

Frozen Peach Long Island Iced Tea

60ml vodka
60ml of spiced rum
60ml peach schnapps
60ml sweet and sour mix
120ml cola
Ice

Place all ingredients except the ice in a bowl with paddle. Shave ice on SNOW CONE setting to desired consistency or until large serving ice line is reached and serve.

Caramel Sour Apple Icy-Tini

60ml vodka
60ml of butterscotch schnapps
75ml of sour apple schnapps
Ice

Place all ingredients except the ice in a bowl with paddle. Shave ice on SLUSHIE setting to desired consistency or until large serving ice line is reached and serve.

Summer Snow Man

Variety of flavoured and coloured syrups
2 tablespoons of water
Small ice cream scoop
Ice

Shave ice on SLUSHIE setting until large serving ice line is reached. Add water. Shape ice into balls with ice cream scoop. Make into snow man shape and drizzle with syrup and serve.

Rainbow Snowcone

Variety of flavoured and coloured syrups
2 tablespoons of water
Small ice cream scoop
Ice

Follow same instructions as Summer Snow Man but place ice balls in paper cup and drizzle with assortment of syrups, then serve.

Important Safety Instructions

Please keep this instruction manual in a safe place, along with the warranty card, purchase receipt and carton for future reference. The safety precautions enclosed herein reduce the risk of fire, electric shock and injury when correctly adhered to.

- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- Before turning on, ensure the electrical voltage and frequency of the circuit correspond to those indicated on the appliance.
- Young children should be supervised to ensure that they do not play with the appliance.
- **CAUTION:** To prevent damage to the appliance, do not use alkaline cleaning agents when cleaning; use a soft cloth and a mild detergent.
- **WARNING:** If the surface is cracked, switch off the appliance to avoid the possibility of electric shock.
- Do not operate the appliance outdoors.
- Make sure the motor and blade have completely stopped before removing the bottle lid. If the machine does not stop, unplug immediately and discontinue further use.
- The power plug must be removed from power socket before cleaning, servicing, maintenance or moving the appliance.
- When the appliance is not in use, switch it off and unplug it.
- To reduce the risk of electrocution, never operate this product with wet hands, submerge under water or spill liquids into the product.
- Do not insert any objects into the appliance.
- Do not blend hot liquids.
- Do not kink or damage the power cord.
- Improper installation may result in the risk of fire, electric shock and or injury to persons.
- The manufacturer is not responsible for any eventual damages by improper or faulty use.
- The unit has no user-serviceable parts contained within. Do not attempt to repair, disassemble or modify the appliance.
- Do not use chemical, steel wool or abrasive cleaners to clean the outside of the unit, as these will scratch the stainless steel and metal surface.
- Do not move the Icy Treats maker while it's switched on.
- Never attempt to move the Icy Treats maker while the surface is hot.
- To protect against electric shock, do not immerse cord, plugs, or unit in water or other liquid. **CAUTION:** Never submerge unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Turn control to "OFF" before unplugging from wall outlet. Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after

Important Safety Instructions

- the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments is not recommended and may cause fire, electric shock or injury.
- Do not let cord hang over edge of table or counter, or touch heated surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for anything other than its intended use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
- WARNING :** The unit is equipped with an interlock mechanism to prevent the unit from operating without the bottle in place. The interlock is a small plastic piece that is pushed down when the bottle is screwed into place. NEVER attempt to defeat or override the interlock mechanism.

Caramel Sour Apple Slushie

1/2 a cup of sour apple syrup
1/2 a cup of caramel syrup
Ice

Place all ingredients except the ice in the bowl with paddle. Shave ice on SLUSHIE setting to desired consistency or until large serving ice line is reached and serve.

Pear Green Apple and Raspberry Granita

120ml of pear juice or nectar
60ml of sour green apple syrup
60ml of raspberry syrup
Ice
Fresh raspberry or green apple slices for garnish

Place pear juice and sour cream in a bowl. Shave strawberries on SLUSHIE setting to desired consistency or until large serving ice line is reached. Pour into glasses, leaving at least 2 inches at top of the glass. Rinse the bowl and paddle.

Place raspberry syrup in the bowl. Shave 225 to 550 grams of ice on SLUSHIE setting. Add to top of pear green apple slushie in glasses. Garnish with fresh raspberry or slice of green apple and serve.

Tie-Dye Slushies

120ml of blue raspberry syrup
120ml of raspberry syrup
Ice
Fresh mint for garnish

Place blue raspberry syrup in the bowl. Shave ice on SLUSHIE setting to desired consistency or until large serving ice line is reached. Pour into glasses, leaving at least 2 inches at top of the glass. Rinse the bowl and paddle.

Place raspberry syrup in a bowl and repeat.
Add 60 to 120ml of red raspberry slushie to blue raspberry slushie. Stir slightly for tie-dye effect, garnish with mint and serve. Try with lime and red raspberry syrup too!

Icy Treats Recipes

TIP: Use convenient ice, liquid, large and small serving markings on bowl as a guide for serving size.

Vanilla Latte Slushie

120ml of vanilla syrup
240ml cold, strong coffee
Ice

Place all ingredients except the ice in a bowl with paddle. Shave ice on SLUSHIE setting to desired consistency or until large serving ice line is reached and serve.

Fresh Strawberry Slushie

180ml of raspberry syrup
180ml of water
680gr of frozen strawberries
225gr of ice


Place all raspberry syrup and water in a bowl with paddle. Shave strawberries on SLUSHIE setting. Shave ice on SLUSHIE setting until large serving ice line is reached and serve.

Pomegranate Freeze

180ml of pomegranate juice
60ml of raspberry syrup
60ml of blue raspberry syrup
Ice
Fresh mint for garnish

Place all ingredients except the ice and mint in a bowl with paddle. Shave ice on SNOW CONE setting to desired consistency or until large serving ice line is reached, garnish with mint and serve.

Parts and Features



How to Operate

1. Make sure the unit is unplugged.
Place base on clean, dry surface.
2. Hook front housing onto base.



3. Place ice shaving chamber in front housing and ensure it is seated on the shaft.



4. Twist shaft in direction of arrow to lock into position.



5. Place mixing paddle in bowl.
6. If mixing shaved ice with other ingredients, place ingredients in bowl.

NOTE: Use serving size markings on bowl as a guide for appropriate ice and liquid levels.

7. Slide bowl into place on base and turn clockwise until it stops at post. This will allow the mixing paddle to mix ice and ingredients once operation begins.



NOTE: The cup guide on base may be used to shave ice into bowl or cup other than bowl supplied.

8. Turn selector knob to desired setting. Slushie setting produces finer ice. Snow Cone setting produces coarser ice.
9. Place ice in shaving chamber. Do not fill above top rim of ice shaving chamber.
10. Plug cord into outlet.
11. Place lid on front housing and turn clockwise to lock interlock switch (Power Start/Stop). The unit will start and begin to shave ice.



NOTE: It may be necessary to open lid occasionally to redistribute ice.

Cut Hazard

- Avoid contact with shaving blade.
- Do not use if shaving blade is loose, cracked, bent or damaged.

12. Turn lid counterclockwise to stop. Do not shave ice above the ICE line.
13. To remove bowl, turn counterclockwise, slide out and serve Icy Treat.

How to clean

1. Unplug unit from electrical outlet.
2. Wash lid, ice shaving chamber, front housing with paddle, and bowl in hot soapy water. Rinse and dry. All removable parts may be washed on the top rack of a dishwasher, or if an energy saver mode is used, top or bottom rack.
3. Wipe the base with a damp cloth. Dry with a soft, dry cloth. Do not use abrasives.

WARNING

Electrical Shock Hazard

- Disconnect power before cleaning.
- Do not immerse cord, plug or base in any liquid.

Failure to follow these instructions can result in death or electrical shock.

WARNING

Cut Hazard

- Avoid contact with shaving blade.
- Do not use if shaving blade is loose, cracked, bent or damaged.

Trouble shooting

PROBLEM	PROBABLE CAUSE / SOLUTION
Ice not shaving	<ul style="list-style-type: none"> • Turn off. Redistribute ice in chamber. • Is lid completely locked into interlock (power Start/Stop) switch? • Is unit plugged in? • Is front housing locked into base? • Is the shaft locked into position? • Ensure ice shaving chamber is placed in front housing AFTER the front housing has been locked onto the base.
Mixing paddle not running	<ul style="list-style-type: none"> • Make sure the bowl has been turned clockwise to stop at post on base
Unit is leaking	<ul style="list-style-type: none"> • Unshaven ice may melt and drip onto base, giving the appearance of leakage. Wipe base dry with a soft cloth. See "How to Clean" section.