

TAYAMA[®]

INSTRUCTION MANUAL

STAINLESS STEEL KETTLE

BM-101



Affordable, Easy to Use, Quality Appliance

Tayama Appliance USA Inc.

Tayama Appliance USA Inc.
www.tayama-usa.com
Email: info@tayama-usa.com

TAYAMA
INSTRUCTION MANUAL
STAINLESS STEEL KETTLE

TAYAMA®

自動電水壺使用說明書

型號：BM-101

本產品是便利，快捷的家用電器，且自動控制。

BM-101 款電水壺煮水快速，安全，節約電源；是家庭，酒店最合適使用的產品。

如何使用您買的電熱水壺？

- 1、裝水前，把電水壺底座和水壺分開。
- 2、打開水壺蓋子裝水，裝水時，要注意看水壺上的標識，水不能超過最高的水位尺位置。
- 3、裝好水後，把水壺放在水壺電源底座上，水壺底座是有連接好的電源線和插頭，把電源插好後，把水壺的開關按鈕“SWITCH ON”按下，燈亮就表示開始煮水。
- 4、當水煮開過後，水壺就自動熄掉，如果想要水再次煮開，等幾分鐘后再次按下“SWITCH ON”鍵，水壺再次煮水。
- 5、第一次使用水壺前，先煮開兩次水，倒掉這些水，然後再用來煮飲水。

如何清洗水壺？

- 1、把插頭，插座鬆開電源後，待冷卻後，清洗。
- 2、不要把電源底座，電源線，插座浸水。

安全警告

- 1、當使用電水壺的時候，小孩勿近！
- 2、如果沒有水壺蓋，不允許使用水壺！
- 3、使用電水壺的時候，必須有人看管！
- 4、電水壺開始熱時，不能接觸電水壺外部！特別是煮開水時，不能用手觸摸出氣孔或者蓋子！
- 5、電水壺裡面沒有水時，水壺必須是鬆開電源插座的。
- 6、不能把電水壺放在發熱的表面上！

TAYAMA®

INSTRUCTION MANUAL FOR AUTOMATIC CORDLESS KETTLE

THIS PRODUCT HAS A UNIQUE AND PLEASANT APPEARANCE. THE AUTOMATIC FUNCTION CONTROL ALLOWS FOR QUICK AND SAFE BOILING OF WATER. THE AUTOMATIC CORDLESS KETTLE IS AN ENERGY SAVING APPLIANCE. FOR HOUSEHOLD USE ONLY.

HOW TO USE YOUR KETTLE

- 1) REMOVE THE KETTLE FROM THE BASE UNIT BEFORE FILLING WITH WATER.
- 2) OPEN THE KETTLE LID AND FILL WITH WATER TO THE INDICATED MARK “MAXIMUM”. WATER MUST NOT BE ABOVE THE “MAXIMUM” CAPACITY OR BELOW THE “MINIMUM” CAPACITY ALLOWED.
- 3) PLUG BASE POWER CORD INTO WALL OUTLET. THEN PLACE FILLED KETTLE ONTO BASE. TURN APPLIANCE “ON” BY PRESSING ON/OFF SWITCH. INDICATOR LIGHT WILL TURN ON.
- 4) WHEN THE WATER HAS BOILED THE APPLIANCE SWITCHES OFF AUTOMATICALLY. TO REBOIL WATER, PLEASE WAIT A FEW MINUTES FOR THE AUTOMATIC DEVICE CONTACT POINT TO RESUME, AND THEN PUSH THE ON/OFF SWITCH TO START REBOIL.
- 5) BEFORE USING THE KETTLE FOR THE FIRST TIME, BOIL WATER WITH THE KETTLE AND THROW AWAY THE WATER, COMPLETE THE PROCESS TWICE BEFORE USING.

CLEANING

- 1) ALWAYS DISCONNECT THE POWER AND LEAVE TO COOL BEFORE CLEANING.
- 2) NEVER IMMERSE THE POWER BASE, CORD AND PLUG IN WATER.

SAFETY WARNINGS

- 1) KEEP CHILDREN AWAY FROM THE KETTLE WHEN IT IS OPENING.
- 2) NEVER USE THE KETTLE WITHOUT THE LID ON.
- 3) THIS APPLIANCE SHOULD NOT BE LEFT UNATTENDED DURING USE.
- 4) DO NOT TOUCH THE EXTERIOR AS IT GETS HOT. WHEN REFILLING THE KETTLE, TAKE CAUTION NOT TO COME IN CONTACT WITH HOT STEAM FROM THE SPOUT OR LID.
- 5) THE KETTLE MUST BE UNPLUGGED WHEN EMPTYING.
- 6) DO NOT PLACE THE KETTLE ON A HOT SURFACE.